

## Operation Instructions for UFO Emergency Pack Remote Test Device

The remote test device has been paired 1-to-1 with the UFO EM Pack before shipping out of factory. However, in the event manual pair is needed, please follow the following procedure:

### Unpairing:

1. Press "B" button on the remote test device for 1 second.
2. Press slowly "B", "A", "B" in sequence, and wait for at least 3 seconds.
3. After three seconds, press "A" button. If nothing happened, then the remote test device has successfully unpaired with the UFO EM Pack. Otherwise, repeat the first two steps again slowly.

### Pairing:

1. Press "B" button on the remote test device for 1 second.
2. Press slowly "A", "B", "A", "B", "A" in sequence, and wait for at least 3 seconds.
3. Now press "A" button. If the LED indicator on the UFO EM Pack begins to flashing slowly, then the remote testing device has successfully paired with the UFO EM Pack. Otherwise, repeat the first two steps again slowly.

Please advise them to watch the following demo video at the 4:27 time mark:  
<https://www.youtube.com/watch?v=SFwRUnXMBUM&t=267s>

### Pairing one remote test device with more UFO EM Packs

It is possible to use 1 remote test device to control up to 10 UFO EM Packs that are within 150-ft range. However, to do this, it is necessary to follow the following procedure to **unpair the remote test device with the UFO EM Packs first, and then pair the same remote test device with all UFO EM Packs (up to 10 pcs) one by one.**