

## Comparison of Aleddra G2 & G3 Emergency T8 Lamps Better Light for Better Life

This NEW and IMPROVED (Gen3) EM LED T8 tube is designed to replace our very popular (Gen1) Battery Backup T8. (Gen3) improvements:

- Better energy efficiency 15W (Gen3) vs. 18W (Gen1)
- Patented anti-electric shock protection, safety switch on both endcaps. This is the same patented design can be found all the standard Aleddra LED T8 retrofit tubes.
- Battery shutoff switch allows distributors and customer to store a "charged tube".
- Improved Lithium battery.





Demonstration video link: <a href="https://youtu.be/qdoEGna1YcY">https://youtu.be/qdoEGna1YcY</a>.

Please Note - If the emergency LED T8 tube is being installed with an on/off wall switch, the Aleddra (Gen2) emergency LED T8 tube should be your choice. For installations without a wall switch (examples: hallways, night lights or stairwells), the NEW Gen3 Emergency LED T8 tube should be your choice. Both the (Gen2) and (Gen3) REQUIRE the ballast to be bypassed or removed). Below is a technical comparison between (Gen2) and (Gen3) EM LED T8 tubes:


## **Gen 3**: Emergency T8

- 90+ Minutes run time in a power outage
- ETL certified Type B T8 (double-end wired with ballast bypass)
- Always on (needs a continuous power source)
- Ease of installation (bypassing ballast)
- Battery shutoff switch for long stocking time
- Doesn't operate with a wall switch

## Gen 2: Emergency T8

- 90+ Minutes run time in a power outage
- ETL certified as regular T8 (Type B singleend wired on both endcaps)
- Both ends need a power source (additional wiring required)
- Battery shutoff switch for long stocking time
- Turns on/off with a wall switch and functions as a regular T8





Gen2 and Gen3 Emergency T8's continue Aleddra's promise on *Better Light for Better Life*. Both are available for sales for US customers. For more information, please email <a href="mailto:info@aleddra.com">info@aleddra.com</a> or call us at 425-430-4555.

www.aleddra.com • eCatalog • sales@aleddra.com • Phone: 1-425-430-4555 • Fax: 1-425-968-9855 • unsubscribe@aleddra.com